


MARES NEMO AIR DIVE COMPUTER

NEMO AIR – FLOW CHART



KEY FEATURES

- 3 BUTTON WIDE-SCREEN FOR SUPERIOR 170° VIEWING
- AIR INTEGRATED – EAN 21% TO 50%
- OPTIONAL PC USB INTERFACE
- RGBM MARES-WIENKE ALGORITHM
- USER-REPLACEABLE BATTERY
- MAXIMUM DEPTH 492 FT.
- 36 HOURS MAX DIVE LOG
- 2 YEAR WARRANTY
- MSRP \$800.

START HERE

- PRESS ANY BUTTON TO TURN ON
- COMPUTER STARTS AT **0. DIVE**
- PRESS +/- TO SCROLL TO MODES
- PRESS "OK" TO GO INTO MODE
- PRESS +/- TO SCROLL
- PRESS & HOLD "ESC" TO RETURN TO PREVIOUS SCREEN



Hold "OK/ESC" button down 2 seconds for backlight illumination

0. DIVE

CURRENT DIVE DATA

Read and Understand
Pages 6 - 30

1. SET DIVE

- 1.1 AIR - EAN - BOTTOM TIME
- 1.2 WATER TYPE
- 1.3 ALTITUDE
- 1.4 PERSONAL FACTOR

2. SET TANK

- 2.1 UNITS
- 2.2 RESERVE AIR HIGH
- 2.3 RESERVE AIR LOW
- 2.4 VOLUME
- 2.5 P.S.I.

3. SET ALARMS

- 3.1 AUDIO
- 3.2 FAST ASCENT

4. SET WATCH

- 4.1 YEAR
- 4.2 MONTH
- 4.3 DAY
- 4.4 12h / 24h
- 4.5 MINUTES
- 4.6 HOURS

5. TIME

DISPLAYS CURRENT
TIME, DATE &
TEMPERATURE

6. SYSTEM

- 6.1 CONTRAST
- 6.2 KEY BEEP
- 6.3 N2 ERASE (Dive Center use)
- 6.4 UNITS
- 6.5 INTRODUCTION DISPLAY
- 6.6 SERIAL NUMBER
- 6.7 FW – Software version
- 6.8 HW – Hardware version
- 6.9 RESET (# of battery changes)
- 6.10 BATTERY TEST

7. PLANNING

DISPLAYS NO DECO TIME
(+) to MAXIMUM 157'
(-) to MINIMUM 39'

8. LOG BOOK

- 8.1 HISTORY OF:
MAX DEPTH
TOTAL DIVE TIME
TOTAL # OF DIVES
COLDEST TEMPERATURE
- 8.2 LOG BOOK DIVE #
MOST RECENT DIVE FIRST
- 8.3 LOG BOOK TECH DATA
(Individual Dive Details)

9. PC LINK

DOWNLOAD DATA
to PC

EXTRA FEATURES

- OPTIONAL AUDIBLE ALARM ON-OFF
- LITHIUM 3V CR2450 BATTERY
- BATTERY LIFE ESTIMATED at 170 DIVES
- SOFTWARE IS USER UPGRADEABLE
- QUICK DISCONNECT H.P. HOSE
- MINERAL GLASS DISPLAY
- USES DRAK USB INTERFACE